


# INSTRUCTIONS FOR USE QUARTZ MOVEMENT WITH DATE

RONDA 11 1/2 715  
RONDA 8 3/4 785

RONDA 11 1/2 751  
RONDA 10 1/2 704  
RONDA 10 1/2 705

# HERBELIN

HORLOGER CONTEMPORAIN DEPUIS 1947



## HANDS

- |                    |      |
|--------------------|------|
| A. Hour hand       | 時針   |
| B. Minute hand     | 分針   |
| C. Seconds counter | 秒針   |
| D. Date            | 日付表示 |

## FUNCTIONS

1. Normal position / Manual winding ↗ (mechanical)  
稼働位置/手巻き(自動巻き)
2. Date correction ↗ or ↘ 回すと日付の調整ができます
3. Stop-seconds time setting  
*It enables perfect synchronization*  
秒針が止まりますので正確な時刻調整が可能になります