


FS E43
GC E65
TC E62



USA & UK

INSTRUCTIONS

Prior to installation please make sure that power is turned off

1. Separate the mounting bar ① from the canopy ② by unscrewing the decorative caps ③ from the threaded posts ④.
2. Attach the mounting plate ① to the electrical box ⑤.
3. Pass the wires through the links of the chain IMAGE A.
4. Make the electrical connections.
5. Secure the canopy ② to the electrical box ⑤ by screwing the decorative caps ③ onto the threaded posts ④.

WARNING

Fixture must be grounded

Do not exceed maximum wattage

Suitable for wet locations

Clean metal with a soft cloth moistened with water

JP

本製品の設置について

本製品を設置する前に本線への通電を必ず遮断してください。

1. ①の部品を②のキャノピーから外し、④のねじから③の飾りキャップを外します。
2. ①の部品を天井の埋め込みボックス⑤に取り付けます。
3. IMAGE Aのよう、本体の電気ケーブルをチェーンに巻き付けます。
4. 本製品と壁面の配線を接続します。
5. ②のキャノピーを⑤の埋め込みボックスに取り付け④のねじに③の飾りキャップを付けます。

注 意

必ずアースを取り付けてください。

本製品は屋外でご使用いただけます。

商品の拭く時は、濡れた柔らかい布をご利用ください。