

THANKO

Model number: MATFANHWH

Operating Instructions

version1.01shi

Table of Contents	
Safety Precautions	2~5
Part names	6
How to use	7~8
Care Instructions	9
Storage Methods	10
Specifications	11
Product Safety	12
After-Sales Service	13



Thank you for purchasing this product.

To ensure safe and correct use of this product, please read and fully understand this instruction manual before use.

Please be sure to read the "Safety Precautions" before use.

※Important: After reading, please keep it in a safe place.

Warranty period: 12 months from the date of purchase

SAFETY PRECAUTIONS

Please be sure to observe

This manual explains the precautions that must be observed to prevent injury to the user or others, and damage to property. Please read this instruction manual carefully and fully understand it before use.

Display Explanation



WARNING

Indicates that incorrect handling may result in death or serious injury.



NOTE

Indicates that incorrect handling may result in injury or property damage.

The items you must observe are explained in the following categories:



Indicates prohibition (things that must not be done).



Indicates a requirement (something that must be done).

- Please be sure to observe the "Safety Precautions" to prevent accidents such as fire, electric shock, and injury.
- Please read all of these "Safety Precautions" carefully before use and use the product correctly.
- After reading them, be sure to keep them in a place where the user can see them at any time.
- If you lend the product to someone else, please give the instruction manual to them as well.



WARNING

• About handling of this product

If any abnormality occurs in the product, discontinue use immediately.

Continuing to use the product while an abnormality is present may result in smoke.

- Fire & shock circuit
- Electric shock & leakage
- Injury.



The power cable or power plug is swollen, deformed, discolored, or damaged. Part of the power cable or power plug is hotter than usual. Power is switched on and off when the power cable is moved. The unit becomes unusually hot or emits a burning smell. The unit does not operate. If you feel a tingling sensation when touching the product, etc.

If any of the above occurs, immediately discontinue use, unplug the power cord from the outlet, and contact your retailer or support center.

SAFETY PRECAUTIONS

Please be sure to observe

WARNING

• About handling of this product



Keep away from gas stoves and other heat generating devices.

May cause malfunction or fire.

Use on a level and stable surface.

Falling and causing injury.



Do not use outdoors or in dusty or dusty locations.

It may malfunction and cause a short circuit or fire.

Do not use near flammable or combustible materials.

Cause of fire.

Do not spray.

Causes fire and malfunction.

Do not use in places with a lot of oily smoke.

Cause of fire.

Do not use for business purposes or other purposes outside the home.

This product is designed for home use. Using it for commercial purposes may cause malfunction or fire.

Do not allow pins or dirt to adhere to the outlet.

Cause of fire.

Do not use in wet places such as bathrooms.

May cause short circuit and electric shock.

Do not immerse the device in water.

Causes short circuits, electric shock, and malfunctions.

Do not drop or subject to impact.

May cause electric shock or malfunction.

Do not use multiple power strips.

Cause of fire.



Do not direct the airflow towards stoves or other combustion appliances.

Cause of fire.

Do not use on an electric carpet.

May cause smoke, fire, and ignition.

Do not insert foreign objects into the gaps.

Causes malfunction and fire.

Do not use for any purpose other than blowing air onto the body.

Causes malfunction and fire.

Do not operate the unit with cloth, paper, or a plastic bag covering or blocking it.

May cause fire or malfunction.

Do not let children use this product alone.

May cause electric shock and injury.

Do not block or cover the air intake or exhaust vents.

Causes malfunction and fire.



Do not modify or disassemble the product. Anyone other than a repair technician should not disassemble or repair the product.

This may cause fire, electric shock, or injury. If a malfunction occurs, please contact our support.



Do not get wet

Do not disassemble

SAFETY PRECAUTIONS

Please be sure to observe

WARNING

• About power plugs and power cables



No wet hands

Do not insert or unplug the power plug with wet hands.

Cause of electric shock.



Do not get wet

Do not soak the power cable or power plug in water or pour water on it.

Causes of short circuits and electric shock.



Do not damage, break, modify, forcefully bending, pull, twist, or bundle the power cable. Also, do not use heavy objects.

Damage to the power cable may result in fire or electric shock.

Do not let infants lick the plug.

Cause of electric shock or injury.

Do not use if the power cable or power plug is damaged, or if the power outlet is loosely inserted.

Causes of short circuits, electric shock, and fire.

Do not use extension cables.

Cause of fire.

Do not use organic solvents (benzine, thinner, petroleum, etc.), chemicals (bleach, disinfectant, etc.), or abrasives when cleaning.

Causes of cracking, electric shock, and flaming.



Insert the power plug firmly all the way to its base.

Causes of fire and electric shock.

Wipe off any dirt that has adhered to the blade of the power plug and the blade mounting surface.

Causes of fire and electric shock.

Use a 100V AC wall outlet alone.

Cause of fire, electric shock, and malfunction.

Be careful not to put your feet on the power cable.

The product falls and causes injury or malfunction.

Unzip all power cables before using.

May cause fire or electric shock.

Do not apply steam to the power plug.

Causes of fire, electric shock, and fire.



Unplug

When unplugging the power plug, be sure to grasp the plug.

Cause of fire, electric shock, and malfunction.

Unplug the power plug from the outlet when cleaning or not using it.

Cause of electric shock, current leakage, and fire due to insulation deterioration.

SAFETY PRECAUTIONS

Please be sure to observe

NOTE

• About handling of this product



It doesn't drag and move.

This causes damage to tatami mats and floors.

Do not directly touch the body for a long time.

Be careful of children and the elderly.
Causes that can harm your health.

Do not expose animals or plants to direct wind.

Cause of harm.

Do not use on pets.

Cause of electric shock or injury.

Don't use it by multiple people.

Causes of injury or malfunction.

Do not use without a filter.

Cause of malfunction.



Do not store in the following places:

- Deformation and discoloration
- Cause of failure.
- Places with high temperature and humidity
- Places exposed to direct sunlight
- Places with a lot of water or humidity
- Place within reach of children
- Places where there is a risk of falling

Do not use on long pile rugs or soft rugs.

Cause of malfunction.

Can't get close to radio or television.

Cause of noise coming into TV and radio.

※Damage to items that occurs when using this product is not covered by compensation.

※Please do not store or use within the reach of small children.

※If you feel any abnormality, please stop using it and contact the support center.

※Failures, damage, modifications, etc. due to customer negligence are not covered by the support warranty.

※We are not responsible for any accidents that may occur if the product is not used correctly.

※Specifications are subject to change without notice for improvement.


※This product is for sale in Japan. Please note that use overseas is not supported.

- This device is not intended for the device to be used by individuals (including children) in need of assistance unless monitored or instructed by a person responsible for safety.
- It is desirable to monitor children to avoid playing with this device.


PARTS NAMES

Main body


• Surface




• Back Side



Operation button



Air volume adjustment button



HOW TO USE

1 Use the operation button and airflow adjustment button to select the mode and airflow rate.

1) Use the operation buttons to set the fan mode.



The airflow continues only while you are riding.



Once you get on, the air will continue to blow for 10 minutes even after you get off.

It will continue (it will stop if you get on again).



On when pressed

For 10 mins

2) Use the airflow adjustment button to set the airflow volume.

|| : Strong

○ : Medium

| : Weak




Weak

Inside

Strong

2 Insert the power plug into the outlet

Use a single AC 100V wall outlet as the power source.




3 Use by standing on the device

Place your feet on the main unit. There is a switch on the bottom of the unit, and the fan will start automatically when you step on it.

※If your body is wet, be sure to wipe off any water before use.


※The main body can fit feet up to about 25cm in size.

※The load capacity of this product is 120kg (static load).




HOW TO USE (CONT.)

- 4 In the 10-minute continuous mode**
After use, be sure to reload the unit and stop the air blowing.



- 5 Unplug the power plug from the outlet**
※ After use, be sure to make sure the air blowing is stopped before unplugging the power plug from the outlet.



- 6 About after use**
If the top surface gets wet during use, wipe it off thoroughly to keep it clean and be sure to dry it before storing.


CARE INSTRUCTIONS

⚠ NOTE

- Do not use organic solvents (benzine, thinner, petroleum, etc.), chemicals (bleach, disinfectant, etc.), or abrasives. (This may cause cracks, electric shock, or fire.)
- When cleaning, be sure to unplug the power cord from the outlet and turn off the power. (This may cause electric shock, fire, or malfunction.)
- This product is not completely waterproof. Do not immerse the product in water or wash it completely. (This may cause malfunction.)

Main unit


If it gets dirty, wipe it with a well-wrung cloth. This product is not completely waterproof. Do not wash it completely.



About draining water

If water gets inside the unit, it will drain out through the drainage holes on the back of the unit.


The installation surface may become wet as water drains, so please wipe it off after use.



Cleaning the air intake


If dust accumulates in the air intake, remove the filter and remove the dust by vacuuming it.

※Be sure to reinstall the filter after cleaning.



STORAGE METHOD

When storing the unit upright, make sure the power cable is not on the bottom.



It is recommended to cover the device to avoid dust.

NOTE

Store away from the following conditions:

- High temperatures and humidity
- Direct sunlight
- Water or humidity
- Out of reach of children
- Where it may fall

SPECIFICATIONS

Size	Width: 260mm x Depth: 270mm x Height: 45mm
Weight	about 950g
Power Supply	AC100V 50/60Hz
Rated Power Consumption	Strong: 115W; Medium: 55W; Weak: 20W
Air Volume Adjustment	Strong; Medium; Weak
Mode	2 types (sound when you ride/continuous 10 minutes)
Load-bearing capacity	about 120kg
Cable Length	about 1.8m
Waterproof performance	IPx2
Material	PC + ABS
Operating environment temperature	-10 ~ 40°C
Operating environment humidity	Less than 90%
Contents	Main Unit, Instruction Manual
Warranty period	12 months from the date of purchase

Regarding product labeling based on the Long-Term Use Product Safety Labeling System

※ The following information, required by JIS, is displayed on the product body to warn users that deterioration over time may increase the risk of injury

	Year of manufacture (The year is displayed in four digits on the unit.) Designed standard usage period: 3 years
	If you use the product beyond its designed standard usage period, deterioration over time may result in fire, injury, or other accidents.

Designed standard usage period

※ Using the product beyond its standard design life may result in fire, injury, or other accidents due to deterioration over time. (Standard design life)

※ This is the standard period from the year of manufacture during which the product can be used safely without any deterioration over time under standard usage conditions, such as operating hours and temperature and humidity.

※ The standard design life is different from the warranty period. It also does not cover accidental breakdowns.

※ Deterioration over time refers to deterioration that occurs due to long-term use or neglect.

▪ Standard conditions of use: According to Japanese Industrial Standards

Environmental conditions	Voltage	AC 100V
	Frequency	50Hz & 60Hz
	Installation	Standard installation
Load conditions		Rated load (wind speed)
Expected time, etc.	Operating Time	0.5 (h/day)
	Number of Operations	1 (times/day)
	Number of Days of Operations	365 (days/year)
	Number of Switch Operations	365 (times/year)

AFTER-SALES SERVICE

If you have any inquiries or would like to request repairs

Please visit <https://www.thanko.jp/view/page/support>
and contact us via the support page.

You can also access it by scanning the QR code.



THANKO